

### Temporary works permit to load/bring into use

<b>Contract/ Project title:</b>	Newbuild Project Newtownshire	<b>Contract number:</b>	007
<b>TW type:</b>	Supporting or restraining plant. Telescopic Crane Pad Design	<b>Permit number:</b>	008
<b>Final inspection date:</b>	31/05/2019	<b>Time:</b>	07.30

<b>Section of TW:</b> e.g. specific location, relevant phase information	Existing highway road adjacent to Newtownshire Hall existing building.
---	--

**This section of TW has been approved for the following load case:**

Plant support platforms

- Load area
- Loading

Liebherr LTM1350, 350 Tonne Lifting capacity Heavy All Terrain Mobile Telescopic Crane.

**The loading of the section of TW must be controlled by the following:**

See examples at bottom of page

Road closure  
YZ Crane & Lift RAMS

Load to be applied within 24 hours from the date and time stated below.  
The permit must be in the possession of the supervisor **directly responsible** for the loading of the TW **before** any loading takes place.

**Temporary works co-ordinator:**

<b>Signed:</b>	<i>A. Bronzeshield</i>	<b>Print:</b>	A.Bronzeshield	<b>Issue date and time:</b>	31/05/2019 07.45
----------------	------------------------	---------------	----------------	-------------------------------------	---------------------

**Permit issued to:**

e.g. PCs TWC, TWS, responsible supervisor

<b>Name:</b>	H.V. Lifter	<b>Company:</b>	YZ Crane & Lift	<b>Date:</b>	31/05/2019
<b>Name:</b>		<b>Company:</b>		<b>Date:</b>	

**Examples of load considerations include, but are not limited to:**

<p>Formwork</p> <ul style="list-style-type: none"> <li>• Rate of pour</li> <li>• Height of pour</li> <li>• Order of loading</li> </ul>	<p>Trench support</p> <ul style="list-style-type: none"> <li>• Maximum depth of trench</li> <li>• Expected water level</li> <li>• Material storage</li> </ul>	<p>Bridge</p> <ul style="list-style-type: none"> <li>• Vehicle loading</li> <li>• Vehicle speed</li> <li>• Wind loading</li> </ul>
<p>Sheet piling</p> <ul style="list-style-type: none"> <li>• Excavation depth</li> <li>• Anchor loads</li> <li>• Anchor levels</li> <li>• Anchor tests</li> </ul>	<p>Falsework and scaffolding</p> <ul style="list-style-type: none"> <li>• Loading plant/equipment</li> <li>• Wind loading</li> <li>• Vibration</li> <li>• Demolition sequence</li> </ul>	<p>Plant support platforms</p> <ul style="list-style-type: none"> <li>• Load area</li> <li>• Loading</li> </ul>